



Intensity | <Intensity +> or <Intensity ->

Press the <Intensity +> or <Intensity -> button to adjust intensity between 0 and 100%.

Color Temperature | <CCT +> or <CCT ->

Press the <CCT +> or <CCT -> button to adjust color temperature (only for Bi-color models).

Channel | <CH 1~8>

Press the one of the <CH 1~8> buttons to control the lights in this channel.

Presets | <SAVE> + <CH 1~8> & <PRESET> + <CH 1~8>

Save: To save the current state of the light to a preset press <SAVE> and one of <CH 1~8> buttons.

Recall: To recall a saved state press the <PRESET> and one of <CH 1~8> button that you used to save the state.

Lock & Unlock | <PRESET> + <SAVE>

Press the <PRESET> and <SAVE> button together to lock or unlock the remote.